

Wire Accumulation Error

ERROR: Wire Accumulation is not filled up

ADDITIONAL NOTES: None

STEPS:

- 1) Check for wire jams, wire tangling and bundling.**
- 2) Check prefeeder roller pressure and tension.**
- 3) Check prefeeder wheels for wear.**
- 4) Check or replace prefeeder B1 sensor.**