

KOMAX 43T

EPROMS ON INPUT OUTPUT BOARD (006955-006961)

INSTRUCTIONS

When trouble shooting a problem with an input/output (I/O) signal, keep in mind that all I/O boards are compatible with the exception of a prom which is mounted on each board. This ten pin prom is located close to the larger connector and is easily identifiable by a white sticker placed on top of the prom. It is this prom which determine what I/O functions the I/O board will do; therefore you must correctly match the prom to the corresponding I/O circuit board.

The list below will assist in matching up the prom and board:

I/O Connector & Board	I/O Prom	Prom P/N:
X120 - 0	A413a	006971
X121 - 1	A414a	006972
X122 - 2	A415a	006973
X123 - 3	A416a	006974
X124 - 4	A417a	006975
X125 - 5	A418a	006976
X126 - 6	A419a	006977
ST ONLY - 7	A420a	006978